

ARMABOT

Turret Drive P/N A0063 Installation Instructions



2. Remove white pegs from bearing holes. Drill blind holes through with a #9 or 13/64" drill. Do not get chips in bearing ball area.



Tape one edge of tension strip onto bearing. Wrap tension strip around bearing tightly and cut 1/8" away from the first edge. Tape 2nd edge to the first edge tightly so no slop is in the tension strip.

Take the 254 tooth belt and flip inside out so the teeth are facing outward. Route the belt along the tension strip starting at where the tension strip was taped to the bearing going equally in both directions. At the point where it gets difficult to put the belt on the bearing, pull the tension strip under the belt so that the belt and the tension strip are co-aligned the whole length of the belt. While holding both on the bearing, slowly move the belt and tension strip up onto the bearing together. At the end it will take a good amount of strength to push the belt and tension strip to the OD of the bearing.

